



To use as a microwave.

As usual, do not run empty, or put anything metallic inside (not even the circular rack which is for traditional oven cooking).

- a) Press microwave button (6) on control panel - see above
- b) Choose power setting* with (13) or (15) see above, then press (14) to select. Normally 100% ; 20% to defrost.
- c) Set cooking time on (13) or (15), or simply press +30secs (17) like on the old microwave
- d) Press Start (18)

*If you don't set the power within 5secs, it will move automatically to cooking time, the next stage.

To use as a traditional convection oven eg for 1 pie or pizza, use low circular rack.

- a) Press button (4) on control panel - see above
- b) Set temperature, can be up to 200f (13) or (15)
- c) Press (14) to select
- d) Set time by pressing (13) or (15). If you want to pre heat the oven, omit this phase, and put food in later
- e) Start (18)

To use other programmes, please see instruction book.